Instruction Manual P2270BA-EN REV D | 2023-07





47BS... Cordless EC Tool



Copyright © 2023 Apex Brands, Inc. All rights reserved.

Disclaimer

Apex Tool Group reserves the right to modify, supplement, or improve this document or the product without prior notice.

Trademark

Cleco[®] is a registered trademark of Apex Brands, Inc.

Apex Tool Group

670 Industrial Drive Lexington, SC 29072 USA

Manufacturer **Apex Tool Group GmbH** Industriestraße 1 73463 Westhausen Germany

1	For This Instruction Manual	5
2 2.1 2.2 2.3 2.4 2.5 2.6 2.7	Safety Warnings and Notes Operator training Intended use Standards General Power Tool Safety Warnings Specific Safety Instructions For Power Tools System Relevant Safety Instructions	. 6 . 6 . 6 . 7 . 8
3	Items delivered	10
4	Storage	10
5 5.1 5.2	Product description Operation elements Functional elements	11
6	Accessories	14
7 7.1 7.2 7.3 7.4 7.5	Prior to initial operation Use of reaction bar Setting up tool holder Charge battery pack Changing LMC Performing a software update	15 15 15 15
8 8.1 8.2	Initial operation Carrying out the rundown Operating status	17
9 9.1 9.2 9.3 9.4	LCD display Result display Status display Operating menu System error messages	18 20
10 10.1 10.2 10.3	Servicing Cleaning instructions Service schedule Lubricants	28 28
11 11.1 11.2	Troubleshooting General tool Infrared data communication between controller and tool	





11.3	WLAN data communication between controller and tool	30
11.4	Reset tool	32
12	Spare parts	33
12.1	Gearing + Attachment 942246PT	33
12.2	Gearing + Attachment 942240PT	35
10.0	Cooring + Attachment 012212DT	27

12	Spare parts	33
12.1	Gearing + Attachment 942246PT	33
12.2	Gearing + Attachment 942240PT	35
12.3	Gearing + Attachment 942242PT	37
12.4	Gearing 942238PT, 942239PT	39
12.5	Attachment	41
12.6	Tool holder	43
13	Service Notes	44
14	Technical Data	46
14.1	Dimensions	46
14.2	Dimension of tool holder 935290 / 935395 (optional)	47
14.3	Performance data	47
14.4	Electrical Data	48
14.5	Ambient conditions	48
15	Service	49
16	Entsorgung	49



1 For This Instruction Manual

The original language of this Instruction Manual is German. This Instruction Manual is intended for any persons working with this tool that do not carry out any programming

Software version: S169252-(...)

The Instruction Manual has the following purposes:

- provides important notices for safe and effective operation.
- describes the function and operation of the cordless EC tool.
- serves as a reference for technical data, service intervals, and spare part orders.
- indicates options.

Further Documents

Number	Document type	
P2260JH	Installation Manual WLAN data trans- mission, Cordless EC tool	
P2372JH	Installation Manual LiveWire Utilities	
P1730E	Procedure description Bolted joint dia- grams	
P2280SW	Programming Manual mPro400GC Standard Software	
P3248C	EG EC Declaration of Conformity Cordless EC tool	

Symbols In The Text

italic	Menu options (e.g., <i>Diagnostics)</i> input fields, check boxes, radio buttons or dropdown menus.
>	Indicates selection of a menu option from a menu, e.g., <i>File > Print</i>
<>	Specifies switches, pushbuttons or the keys of an external keyboard, e.g., <f5></f5>
Courier	Filenames and paths, e.g., setup.exe
•	List
-	List, level 2
a) b)	Options
\rightarrow	Result
1. () 2. ()	Action steps
	Single action step

Symbols In Graphics

	Movement in one direction		
	Function and force		
7			

Abbreviation

Л

 \leftarrow

Abbreviation	Description	
47BS	Stands for all versions of the cordless EC tool/LiveWire described here.	
EV	Stands for all versions of the power supply described here: Battery pack or Power module.	
LMC	Stands for the LiveWire Memory Chip memory module.	



2 Safety

2.1 Warnings and Notes

Warning notes are identified by a signal word and a pictogram:

- The signal word describes the severity and probability of the impending danger.
- The pictogram describes the type of danger.



Danger

A symbol combined with the word **Danger** indicates a hazard with a **high level of risk** which, if not avoided, will result in death or serious injury.



Warning

A symbol combined with the word **Warning** indicates a hazard with a **medium level of risk** which, if not avoided, could result in death or serious injury.



Caution

A symbol combined with the word **Caution** indicates a hazard with a **low level of risk** which, if not avoided, could result in minor or moderate injuries or environmental damage.



Note

An symbol combined with the word **Note** indicates a potentially harmful situation which, if not avoided, could result in damage to the equipment or the environment.



General notes

Includes application tips and useful information but no hazard warnings.

Structure Of Warnings



Caution

Type and source of danger.

Possible consequences of non-observance.

Measures to avoid danger.

Symbols On The Product

Be sure that you understand their meaning before operation.



Class 2 laser product



CE compliant The product corresponds to the prescribed technical requirements in Europe.



Read all instructions.



Observe generally valid disposal guidelines such as, in Germany, the Electrical and Electronic Equipment Act (ElektroG) and the Battery Act (BattG).

EAC

CE compliant The product corresponds to the prescribed technical requirements in Europe.

2.2 Operator training

All operators must be trained and experienced before operating the tool. The tool may only be repaired by authorized personnel.

2.3 Intended use

The tool is a part of the APEX tightening system and is exclusively intended for fastening and releasing threaded fasteners.

- Use only in connection with a nutrunner controller of the mPro400GC series and the accessories and cables approved by APEX.
- Only operate with a power supply from APEX.
- Do not use as a hammer or for re-bending.
- Do not open it or modify it structurally.
- Do not use it in areas where there is a risk of explosion.
- Only in EMC Limit Class A (electromagnetic immunity for industrial areas).

2.4 Standards

It is mandatory that national, state, and local codes and standards be followed. Other type-specific standards see *Technical Data*.

2.4.1 FCC and IC compliance

This product complies with Part 15 of the FCC Rules. Any changes or modifications not expressly approved by the manufacturer could void the user's authority to operate this product. Operation is subject to the following two conditions:



- this product may not cause harmful interference, and
- this product must accept any interference received, including interference that may cause undesired operation.

FCC Responsible party

Name: William Cain Position: Director, R&D Address: 670 Industrial Drive Lexington, SC 29072 United States Phone: +1 803 951 7558 Email: William.Cain@ClecoTools.com

This product has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the product is operated in a commercial environment. This product generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications.

Operation of this product in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

2.4.2 Canada conformity

Operation satisfies the following two prerequisites: (1) the device does not cause any impermissible failure, and (2) the device accepts failure, including failures which cause unwanted operation of the device.

2.4.3 EMC, noise, vibration

For the currently observed EMC standards, emission sound pressure levels and vibration values, see the EC Declaration of Conformity.

2.5 General Power Tool Safety Warnings

WARNING! Read all safety warnings, instructions, illustrations and specifications provided with this power tool. Failure to follow all instructions listed below may result in electric shock, fire and/or serious injuries. Save all warnings and instructions for future reference. The term "power tool" in the warnings refers to mains-operated (corded) power tool or battery-operated (cordless) power tool.

1 Work Area Safety

- a) Keep your work area clean and well lit. Cluttered or dark areas invite accidents.
- b) Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust. Power tools create sparks which may ignite the dust or fumes.
- c) Keep children and bystanders away while operating a power tool. Distractions can cause you to lose control.

2 Electrical Safety

- a) Power tool plugs must match the outlet. Never modify the plug in any way. Do not use any adapter plugs with earthed (grounded) power tools. Unmodified plugs and matching outlets will reduce risk of electric shock.
- b) Avoid body contact with earthed or grounded surfaces, such as pipes, radiators, ranges and refrigerators. There is an increased risk of electric shock if your body is earthed or grounded.
- c) **Do not expose power tools to rain or wet conditions.** Water entering a power tool will increase the risk of electric shock.
- d) Do not abuse the cord. Never use the cord for carrying, pulling or unplugging the power tool. Keep cord away from heat, oil, sharp edges or moving parts. Damaged or entangled cords increase the risk of electric shock.

3 Personal Safety

- a) Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication. A moment of inattention while operating power tools may result in serious personal injury.
- b) Use personal protective equipment. Always wear eye protection. Protective equipment such as a dust mask, non-skid safety shoes, hard hat or hearing protection used for appropriate conditions will reduce personal injuries.
- c) Prevent unintentional starting. Ensure the switch is in the off-position before connecting to power source and/or battery pack, picking up or carrying the tool. Carrying power tools with your finger on the switch or energising power tools that have the switch on invites accidents.
- d) Remove any adjusting key or wrench before turning the power tool on. A wrench or a key left attached to a rotating part of the power tool may result in personal injury.
- e) **Do not overreach. Keep proper footing and balance at all times.** This enables better control of the power tool in unexpected situations.
- f) Dress properly. Do not wear loose clothing or jewellery. Keep your hair and clothing away from moving parts. Loose clothes, jewellery or long hair can be caught in moving parts.
- g) Do not let familiarity gained from frequent use of tools allow you to become complacent and ignore tool safety principles. A careless action can cause severe injury within a fraction of a second.

4 Power Tool Use And Care

- a) **Do not force the power tool. Use the correct power tool for your application.** The correct power tool will do the job better and safer at the rate for which it was designed.
- b) Do not use the power tool if the switch does not turn it on and off. Any power tool that cannot be con-

trolled with the switch is dangerous and must be repaired.

- c) Disconnect the plug from the power source and/or remove the battery pack, if detachable, from the power tool before making any adjustments, changing accessories, or storing power tools. Such preventive safety measures reduce the risk of starting the power tool accidentally.
- d) Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool. Power tools are dangerous in the hands of untrained users.
- e) Maintain power tools and accessories. Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the power tool's operation. If damaged, have the power tool repaired before use. *Many accidents are caused by poorly maintained power tools.*
- f) Use the power tool, accessories and tool bits etc. in accordance with these instructions, taking into account the working conditions and the work to be performed. Use of the power tool for operations different from those intended could result in a hazardous situation.
- g) Keep handles and grasping surfaces dry, clean and free from oil and grease. Slippery handles and grasping surfaces do not allow for safe handling and control of the tool in unexpected situations.

5 Service

a) Have your power tool serviced by a qualified repair person using only identical replacement parts. *This will ensure that the safety of the electric tool is maintained.*

2.6 Specific Safety Instructions For Power Tools

The term "power tool" in the warnings refers to mains-operated (corded) power tool or battery-operated (cordless) power tool

- a) Do not exceed a total tool cable length of 45 m. Exception:
 - 30 m when used with an mPro400GCD-S(H)-STO.
 - 30 m when used with 70 series tools.
- b) Our insulation is not insulation in the sense of VDE standards: Hold the device at the insulated handle surfaces when you perform work where the screw can strike hidden power lines or your own power cable. Contact between the screw and a live power line could energize metal parts of the tool and cause an electric shock.
- c) Hold the tool firmly. Be prepared for torque reaction.
- d) Reaction bars are recommended in applications with limited space and when using:
 - Inline tools used above 4 Nm.
 - Pistol tools used above 10 Nm.
 - Angle tools used above 60 Nm.
- e) NEVER rest your hand on the reaction bar when working.
- f) Check that the suspension bail is properly secured to the balancer.

Personal Protective Equipment

Risk of injury by being wound up in and caught by machinery

- a) When working with rotating parts, it is not permitted to wear gloves. Recommendation: Freely rotating *u*-*GUARD* protected fastening tools from APEX.
- b) Wear a hair net, if necessary.

Power Tool Use And Care

- a) Only use bits or sockets designed for industrial use with machine-controlled tools.
- b) Make sure that the bit or socket is securely inserted.
- c) Do not attach the bit or socket to the screw head at an angle.
- d) Inspect the bit or socket for visible damage and cracks. Replace damaged screw bits immediately.
- e) Cordless EC tools: Do not open the battery pack.

2.7 System Relevant Safety Instructions

Follow national, state and local safety and connection standards during installation. The standards take precedence over the information in this section.

- Do not make any modifications to the controller, protective devices, or accessories without prior written authorization from Apex Tool Group.
- Do not attempt to open the controller or components of the controller for troubleshooting or other work on the device. In the event of a fault, any intervention can result in serious injury from electric shock.

Operation with the device open may also cause the following:

- An increased amount of emissions: may produce interference with other devices.
- Reduced immunity from interference: may produce faulty results.
- Loss of remaining warranty period.

Risk Of Injury Due To Electric Shock

The controller and tool can conduct current in the event of a fault. An electric shock can lead to cardiac arrest, cessation of breathing, burns, and serious or fatal injuries.

- Always turn off the controller before connecting power and tool cables, cleaning or removal from operation.
- Do not operate the tightening system if the housing, cable or tool are damaged.

Installation

- Ensure the controller is rigidly mounted and secured(see Quick Installation Guide).
- Organize cables and lines to avoid damage and tripping hazards.
- Observe the permitted cable bending radius.

In the event of a fault, high leakage currents may occur and cause injuries by electric shock.

Use an approved power cable, with suitable ratings.



Prior To Initial Operation

- Only operate on a grounded power supply with a neutral conductor (TN system). Operation without a neutral conductoron (IT system) is not permitted.
- Ensure a standard-compliant PE connection is in place.
- A ground fault circuit interrupter (GFCI) type A is recommended to protect the supply line.
- Prior to initial operation, carry out the protective conductor measurement in accordance with the local regulations (in Germany, DGUV Regulation 3).
- Do not switch on the controller until all connections have been made correctly.

Operation

- Protect the controller from moisture.
- Immediately power off the controller in the event of unusual noise, heating or vibration from the tool.
- Disconnect the power cord and have the tightening system checked by qualified personnel and repaired if necessary.
- Never pull the power cord to remove from an outlet.
- Protect all cables from heat, oil, sharp edges and moving parts.
- Replace damaged cables immediately.
- Ensure tool and plug connections between the controller and tool are clean.
- Ensure the workstation and surrounding area are clean.
- Ensure the workstation provides adequate space for the operation being completed.
- When working with a nutrunner, remain alert at all times. Do not use a nutrunner if you are tired or under the influence of drugs, alcohol or medication. A moment of carelessness when working with a nutrunner may contribute to a life threatening situation.

Danger Due To Incorrect Torque Measurement

An undetected NOK tightening may contribute to a lifethreatening situation.

- Recalibration (or capability analysis) is essential following incorrect use (crash, mechanical overload...).
- For Category A Tightenings (VDI 2862) which are critical for safety, activate a redundancy measurement (e.g., current redundancy).
- Introduce regular monitoring of measuring equipment for associated manufacturing equipment.
- Only conduct tightening operations with a properly functioning system. If in doubt, contact Sales & Service Center.

Danger Due To Unexpected Start Of The Motor Or An Expected But Missing Stop

Despite redundant controller parts and monitoring functions, an unexpected start of the machine can occur in very rare cases. Possible reasons may include, but are not limited to: Remote control of diagnostic functions, bit dump in the memory of the controller.

Mechanical hazards such as jars/jolts due to counter torques; risk of injury due to winding up and seizing can result from the tool.

Use the tool at the designated grip points.

- Use the recommended reaction devices. For torques, reference appropriate tool instruction manual.
- After powering the controller on, wait until the boot cycle is completed, approximately 60 seconds, before powering it down again.

Maintenance

- The controller is generally maintenance-free.
- Consider local regulations for maintenance and servicing for all operating phases of the tightening system.

Cleaning

- Only clean the exterior of the tool using a dry or slightly damp cloth.
- Do not immerse the controller or tools in any liquids.
- Do not use a high pressure or abrasive cleaner.
- Disinfection of surfaces with alcohol-based disinfectant is permitted.

Repair

Repairs to the equipment are not permitted.

Send the controller to a Authorized Cleco Production Tools Sales & Service Center.

Disposal

Components of the tightening system may present potential risks the environment. The tightening system contains components that can be recycled, as well as components that have specific disposal requirements.

- Follow local applicable regulations.
- First separate, then dispose of components.
- Collect auxiliary materials (oils, greases) and dispose properly.
- Separate the components of the packaging and dispose of them according to local regulations.
- Return defective equipment to an approved collection point or return it to the Sales & Service Center.



Observe local regulations for disposal of electronics and batteries. (In Germany, the Electrical and Electronic Equipment Act (ElektroG) and the Battery Act (BattG)):

Used up batteries must be disposed of properly. Return depleted or defective batteries to an approved collection facility or to Sales & Service Center for recycling.



3 Items delivered

Check delivery for transit damage and ensure that all items have been supplied:

- Cordless EC tool
- This instruction manual
- Declaration of Conformity
- Tool Certificate
- Machine Capability Analysis (MCA)

4 Storage

For short-term storage and for protection against damage

Place the tool in the tool holder.

For storage longer than 100 hours

Disconnect the battery pack from the tool. The battery pack is discharged by the electronics integrated in the tool.

For the storage temperature, see 14.5 Ambient conditions, page 48.



5 Product description

- Sturdy, brushless motor with resolver. Shutoff is torque/angle-controlled.
- LCD display with information on status, torque, and angle.
- Green OK and red NOK LED display provides information about current fastening result.
- LED lighting makes it possible to find the screw point quickly.
- Clockwise/counterclockwise rotation
- Fastening parameters are set with the controller or a PC.
- An exchangeable memory module (LiveWire Memory Chip) allows the quick exchange of identical tools, without changing the parameters.
- Depending on the type, data is transmitted between the control and the tool via
 - Infrared (IrDA)
 - WLAN
- Built-in acoustic signal.
- The Stay alive function of 15 seconds, prevents a restart during the battery change and thus saves time. The LEDs flash during this process (buffer mode).



ltem	Designation	
<f1>, <f2></f2></f1>	Function keys	
2	LED display	
3	Start button	
4	Reverse switch	
5	IrDA (infrared interface port)	
7	LED lights for fast location of the fastening position	
9	LCD display with information on torque, angle, and status	

ltem	Designation	
11	Wireless module	
12	LiveWire Memory Chip (LMC)	

5.1 Operation elements

5.1.1 Function keys

Left function key <F1>

<f1></f1>	Function	
Press once.	 Confirm error message. Programmable: Depending on how the key is programmed, actions can be carried out by pressing it briefly. 	
Press for two seconds	Exit menu	

Right function key <F2>

<f2></f2>	Function	
Press until the display shows the <i>Main</i> <i>menu</i> (refer to 9.3.4 Adminis- tration sub- menu, page 22).	Activate menu.	
Press for two seconds	 Select functions, if menu is activated. Alternatively, the start button can be pressed. 	

5.1.2 Start button

Depending on the setting, the start button has three functions:

- It activates the LED lighting.
- Press the start button halfway down and hold it.
- It starts the motor, the LED light goes out.
- Press the start button all the way down.
- It activates the barcode scanner.
- Press the start button all the way down.

5.1.3 Reverse switch

The reverse switch changes the rotation direction of the tool:

Clockwise rotation – for screwing in screws

- Press reverse switch as far as it will go.
 - → When the start button is pressed Active appears on the LCD display.

Counterclockwise rotation – for loosening or screwing out screws

- Press reverse switch as far as it will go.
 - → When the start button is pressed *Left* appears on the LCD display.

5.2 Functional elements

5.2.1 LED display

The LED display shows the respective operating status and the result of the last fastening sequence (see 8.2 Operating status, page 17):

LEDs	Operating status	Result after fastening cycle
Continuous green light	Active	OK
Continuous red light	Active	NOK
Flashing light Green – low frequency	Energy saver mode	
Off	Sleep	
If linking is selected on the controller:		

_		
Green flash- ing light – high frequency	Active/Setting: Linking	Linking OK
Flashing red light	Active/Setting: Linking	Linking NOK

Software update

During the *software update*, the actual programming process is indicated by rapid flashing alternating at irregular intervals between red and green.



Do not interrupt programming by disconnecting the power supply during this phase.

5.2.2 IrDA interface port

The tool communicates with the controller over the tool holder via the IrDA interface port (infrared). For secure

data transmission and for programming, place the tool in the tool holder with IrDA interface port

5.2.3 Identification – set torque (accessories, optional)

To identify the tool with the set torque, glue the corresponding marking foil to the right and the left of the LCD display.



5.2.4 LED lighting

LED lighting make it possible to quickly find the screw point.

3 different activation methods are possible. Which is used depends on the programming in the control:

- Activation by pressing the start button halfway down (5.1.2 Start button, page 11).
- Time-controlled beginning at start
- You also have the option of disabling it.

The range of the LED illumination is 120 mm.

5.2.5 Power supply

The power supply can take place via:

- 26 V / 44 V battery pack
- 48 V power module

The maximum tool speed depends on the power supply used. The higher the voltage of the power supply, the higher is the maximum speed of the tool. The maximum speed of the standard 26 V battery packs is specified on the tool.

Target speed parameter in screwing sequences must be adjusted to use the higher speeds with the 44 V/48 V power supply.



Note

If the tool is operated with a 44 V/48 V power supply for the first time, the maximum speed in the self-identification data of the tool is permanently increased.

In this is the case, note the following:

- Use at least the LiveWire software version S169251-123.
- Adjust the speed parameters in the reference values to be able to use the higher speeds.
- At higher speeds, higher reaction torques are to be expected. This can lead to surprise effects and risk of injury.
- Due to the higher kinetic energy at higher speed, the shut-off point can be passed over. Shut-off point adjustment need to be checked.
- Perform test tightening with the new parameters.
 - Tightening behavior may change and may require further adjustments.
 - Tightening time changes. Adjustment of process monitoring tmax is necessary..
 - With changing power supplies, the higher target speed with the battery pack 26 V can not necessarily be achieved (Δ tmax).
- To reset the maximum speed to the value of 26 V operation, contact the Apex Tool Group service department.

See instruction manual for battery pack

5.2.6 LCD display

See 9 LCD display, page 18

5.2.7 Wireless interface

Communication	Required remote station
WLAN Standard IEEE	Access Point nach Stan-
802.11ac/b/g/n	dard IEEE ac/b/g/n

The tool uses this wireless interface port for continuous communication with the controller. This interface port is used to transmit both the parameters and the rundown results. Data transmission is possible in the *Active*, *Energy saver mode* and *Standby* operating modes, but not possible in *Sleep* (see 8.2 Operating status, page 17). Programming and setting up the wireless interface port are described in the programming manual of the controller.



After the tool is switched on, it can take up to 35 seconds until the communication is active.

5.2.8 LiveWire Memory Chip (LMC)

To permit simple replacement of tools in production, a replaceable LMC memory module is installed. When the tool is switched on, the network settings are read from the LMC chip and used to establish the WLAN connection. When the tools are changed, the LMC has to be installed in the new tool being used. Please refer to 7.4 Changing LMC, page 15.

The following data are stored on the LMC:

- MAC address
- Network name (SSID)
 - Encryption
- Network key
 - Use of the DHCP
- Roaming settings
 Channel selection
 - server .
 - Network certifikates

IP address

Gateway

Subnet mask

Country-specific settings

API license

The MAC address is defined by *Cleco* and cannot be changed. The other data can be changed via infrared connection of the tool to the controller.



6 Accessories

	Battery pack 26 V HC, li-ion, Order No. 961101PT
Vingx	Battery pack 44 V HC, li-ion, Order No. 961102PT
- Inder Maria	Battery charger 26/44 V, li-ion Order No. 962085PT
0	Adapter cable PM48 Order No. 961341-030 – 3 m Order No. 961341-060 – 6 m Order No. 961341-080 – 8 m Order No. 961341-100 – 10 m
O ť	Extension cable: Adapter cable PM48 Order No. 961342-030 – 3 m Order No. 961342-060 – 6 m Order No. 961342-080 – 8 m Order No. 961342-100 – 10 m
	Tool holder with IrDA interface Order No. 935290 – up to 65 Nm Order No. 935999 – starting from 70 Nm
	without IrDA interface, Order No. 935395 – up to 65 Nm Order No. 935998 – starting from 70 Nm
	RS232 extension cable (IrDA) Order No. 935154 – 3 m (9.84") Order No. 935155 – 6 m (19.7") Order No. 935157 – 10 m (32.8")
	Power Module PM48 Order No. 961350PT
	IrDA adapter Order No. 935170
(f)	Laminate Order No. 935330: 1.5 – 28 Nm Order No. 935759: 30 – 49 Nm
000	LMC Order No. 961461PT

P2270BA | REV D | 2023-07



Prior to initial operation

The tool was preset by Apex Tool Group. A setting for your specific fastening sequence must only be made with the controller or a PC by a qualified person. For more information, refer to the programming manual.

Use of reaction bar 7.1

Caution

Danger of hands being crushed.

Always use a reaction bar for applications in restricted space and torques over 60 Nm.



Fig. 7-1: Fixing the reaction bar

7.2 Setting up tool holder

- Mount the tool holder on a stable base. 1.
- 2. Place the tool in the tool holder with IrDA interface portData transmission is possible in the Active, Energy-saver mode and Standby operating modes, but not possible in Sleep mode (see 8.2 Operating status, page 17).



If the data transmission has been interrupted, the LCD display reports a synch error.

Replace the tool in the tool holder. The complete data transmission is acknowledged on the display with Rest 512.

3. Select the location in such a way that no outside light shines onto the tool holder.

This can inhibit data transmission.

- 4. Lay the connection cable in such a way that there is no danger that persons can trip.
- Programming see document P2372JH. 5.

7.3 Charge battery pack

Battery pack is only partly charged upon delivery.

It must be fully charged before initial use. See battery ► pack instruction manual.

7.4 Changing LMC

Note

Electrostatically sensitive component.

The electronic assemblies of the cordless EC tool can be destroyed or damaged by electrostatic discharge (ESD). This can lead to immediate failure, or to malfunctions at a later date.

- Note handling instructions.
- ► To avoid damage when changing the LMC, make sure that there is a potential equalization between the person and the tool.
- Possibly set up equipment in an ESDprotected environment. Recommendation for an ESD workplace: Electrically conductive work surfaces, anti-static straps, appropriate furniture, clothing and footwear, as well as grounding of all components.

LMC must only be changed with the battery is disconnected.



Fig. 7-2: ESD workplace

LMC

- 1. Remove the battery.
- 2. Slacken the screws (M4, DIN 912).
- Carefully pull the LMC out of the handle and replace it. 3.



Fig. 7-3: Remove LMC

Inserting LMC

- 1. Carefully insert the LMC as shown in the illustration.
- 2. Tighten the screws (M4, DIN 912).
- 3. Insert the battery.





Fig. 7-4: Inserting LMC

7.5 Performing a software update

Perform update, see document P2372JH. Do not remove the battery pack during the software update!

7 EN



8 Initial operation



Warning

Risk of glove being pulled in due to rotating machine parts.

Risk of fingers being crushed or lost.Do not wear gloves when working with this tool.

8.1 Carrying out the rundown

Ensure secure position of the power supply before starting the tool. The tool is now ready for operation.

Press and release the start button: Rundown is executed, the LCD display shows *Ready*.

Types with wireless transmission continuously communicate with the controller. The tool automatically receives the parameters and, when the rundown is complete, automatically sends the rundown results to the control system. Programming and setting up the wireless interface port are described in the programming manual of the controller. Types without wireless transmission must be placed in the tool holder when the rundown is complete. The rundown results are transmitted and shown under the *Run screen* menu item.

8.2 Operating status

The following functions are available depending on the display:

The	anarating	madaa	abanaa	in t	had	following or	dor
nne	operating	moues	change	ΠIL	ne i	following or	uer.

Operat- ing status	LED display	LCD display	Function
Active	Continuous light: Red – Fasten- ing NOK Green – Fasten- ing OK	On	screws Data transmis- sion
^a After 1 min	ute idle time automa	itic switch to	:
Energy saver mode	Green flashing light	Off	Data transmis- sion
Automatic sv further 10 mi	vitch to the following nutes:	after a	
Sleep	Off	Off	Data transmis-

	-	
		transmis-
		sion not
		possible
Λ.	£	

Manual change from *Sleep* to *Active*:

Press the start button fully down and hold it for about 1 second.

For manual deactivation of the tool, disconnect the power supply.

a.) Times are default values and can be programmed in the controller.

This operating mode maintains the logic supply for up to 15 seconds during the battery pack change:



9 LCD display

The LCD display on the tool is divided into the result display, status display, operating menu and system error messages.

9.1 Result display



The LCD display consists of a three lines, each with 6 characters, to display the status, torque and angle. The result display is updated after the rundown ends.

First line – result:

ОК	Result is OK
NOK	Result is not OK
OFF	Torque encoder offset error
CAL	Torque encoder calibration error
ENC	Angle encoder error
IP	Current overload in output section
ШΤ	Requested motor output is too high
TMAX	Maximum fastening time exceeded
RC	Rundown terminated by disabled start signal
Tq<	Torque too low
Tq>	Torque too high
WI<	Angle too small
WI>	Angle too large
Error	Error occurred
AW<	Too few graphic values recorded for an evalu- ation (SEQ 31/51)
BLOC	Fastened to block / tightened screw fastened (SEQ 31/51)
IRED	Current redundancy error
JMP	Bit jump detected
MBO>	Torque has exceeded top evaluation torque (SEQ 31/51)
MBU<	Torque has fallen below bottom evaluation torque (SEQ 31/51)
MDSI	Safety torque exceeded (SEQ 31/51)
SS>	Time for stick-slip too large
SST	Too many stick-slip edges
TTT<	Time since TT too small
TTT>	Time since TT too large

The status is displayed in alternation with the Application being used.

Second line – Shut-off torque in Nm:

- T Shutoff torque
- Third line Shut-off angle in degrees:
- A Shutoff angle

OK ▼ T12.00 A100 The Y symbol at the top right shows an interrupted data connection to the control.

9.2 Status display

The status display is divided into the "Standard" and "Linking" modes. "Standard" is selected if "Linking" is not enabled at the control system.See Navigator > Advanced > Linking. The application is selected at the <Run Screen> or via the Application Select inputs.



No other status messages take priority. The tool is ready.



Number of remaining rundowns that can still be carried out until the rundown data memory is full and the rundown data have to be transmitted to the control.



All fastening sequences have been completed.

Synchronize the tool with the control once again.



No fastening sequences have been initialized.

 Synchronize the tool with the control once again.



App

locked

Sync

No fastening sequence parameters have been set.

Check the Application and Tightening group selected on the control to determine whether the tool settings and process programming have been carried out.

Application locked.

 Synchronize the tool with the control once again.



Reject Releas Sync Reject Release active.

The Reject Release was programmed in the control.

- 1. See Navigator > Advanced > Tool Group > Tightening > Reject Release.
- Depending on the programming, unlock the tool via the external input NOK release or Release on Backoff. For unlocking via the external input NOK release, set the external input and synchronize it with the control.

Sync Error Error in last data synchronization with the control.

 Synchronize the tool with the control once again.

Tool not set Tool has not yet been synchronized with a control.

 Synchronize the tool with the control for the first time.

Input Enable Missin

- The Tool Enable input is missing.
 Activate External Tool enable in Process programming > Advanced >Tool Settings.
- 2. Synchronize the tool with the control once again.

This message can only appear if in *Navigator* > *Advanced* > *Tool Settings* > *External release* has been activated.

Need Part ID No barcode was detected within the timeout or an invalid barcode was read. The display switches to *Expect barcod*. Scan the barcode in again.



Tool waits for job from the control. If no job within 5 seconds:

Scan the barcode in again.



Tool waits for a barcode to be scanned.



Barcode was read successfully and confirmed by the control.

WLAN init.. Initialization of WLAN chip and WLAN module.



Optional -XXXXXX rundowns remaining until next service.



Service interval—the tool is blocked. No rundowns possible.

Return tool to Sales & Service Centers for service.

Additional messages in "Linking" mode

Optional -

The regular sequence is carried out in automatic mode, which is configured by default. Only for the emergency mode is an emergency operation enabled or disabled via a scan.

P 1/16 0ZZ899 99

N.Pos1

of 3

Rpl 0

Linking display, if this is programmed in the job, here link position 1 of 16 for WK-ID 0ZZ89999.

First line: The next position to be fas-

tened. Second line: Number of positions. Third line: Number of repetitions at this position in case of an NOK rundown.



Linking has been canceled without a batch result.

Not all of the positions in the tightening group have been programmed.

Check the Application and Tightening group selected on the control to determine whether the tool settings and process programming have been carried out.



Linking result OK.



Linking result NOK.

rol P1



Linkin locked Synch

Linking disabled. Synchronize the tool with the control once again.

Linkin No Job

Wait for end of transmission.

Synchronize the tool with the control once again.

Operating menu 9.3

9.3.1 General

The operating menu on the tool is divided into a main menu and submenus. You can navigate through the menus using the two function keys below the LCD display. In the following description, <F1> is used for the left function key and <F2> is used for the right function key. The menu is activated by pressing the right function key, <F2>. The menus can be disabled by configuring appropriate parameter in the controller.

Basic functions:

- <F2>: Activate main menu.
- <F1>: Go to previous menu item.
- <F2>: Go to next menu item.
- Press <F1> longer than 2 seconds to go to the next higher menu level. If the main menu is activated, the system goes into production mode.
- Press the start button or <F2> longer than 2 seconds to activated the highlighted item or execute the highlighted action. Actions that start the tool can be carried out only by pressing the start button.
- If the menu is enabled, no rundowns are possible.
- At the end of each submenu there is an entry for Back.



Enables the main menu.



9.3.2 Structure



9



>Main



Admini strati	Time, Counter display, etc.
>Main Diag- nostic	Diagnostic functions for the tool.
>Main Posi- tion	Optional – <i>Position</i> – Selects the position to be used next.
>Main Scan- ner	Optional – Deletes a previously read barcode and activates a new read cycle.
>Main LMC	Shows Settings LiveWire Memory Chip.

Shows general items such as Date/

Counter status

The tool counter display is incremented after each rundown throughout the service life of the tool. Refer to control under Diagnostics > Tool > Tool Memory.



Counte

99

XXXXXX

Optional -

Active when service counter was activated by Apex Tool Group. Number of rundowns under load.



Optional -Active when service counter was activated by Apex Tool Group.

Number of rundowns until next service.



Serial number Serial no. display.



Control software version

Displays the installed software version.



Shows settings of wireless transmission.



Servo software version

Displays the installed software version.

9.3.4 Administration submenu



Date / Time

Displays the tool system time.

The system time can be displayed in US or European format.

Refer to "Setting the system time on the control" under Administration > Date > Time.

Set the system time, refer to Con-► trol.

Date	
06.07.	
2023	

Date

Displays the date. The date can be displayed in US or European format.

Refer to "Setting the system time on the control" under Administration > Date > Time.

Set the system time, refer to Con-► trol.



9.3.5 Diagnostics submenu

Cal OK
K 1.11
O 0.00

TQ calibration

This test function cyclically recalibrates the system with the values used immediately before the start of a rundown. For this, the tool must not be tensioned! First line: Calibration test and status. Second line: TQ calibration voltage. Third line: Offset voltage. If a value lies outside the tolerance range, the corresponding error is displayed.

Valid until transducer serial number 168696:

Value	Rated value	Tolerance
TQ calibration voltage	1,10 V	± 45 mV
Calibration offset	0 V	± 58 mV

Valid from transducer serial number 168696:

Value	Rated value	Tolerance
TQ calibration voltage	1,21 V	± 0,05 V
Calibration offset	0 V	± 0,05 V



TQ measurement

In this test function, after the start button is pressed, the same calibration is carried out as immediately before the start of a rundown. For this, the tool must not be tensioned!

Then, the tool starts with speed "0". The torque is continuously measured and displayed until the start button is released. Second line: Current torque.

Third line: Peak value, highest value since the start button was pressed.

Angle A 360 OK

Angle encoder

The start button starts the tool at 30% of the maximum speed. After one revolution of the output shaft (nominal angle 360°), measured with the resolver, the tool is stopped. During a fixed dwell time of 200 ms, any further angle pulses occurring are traced. The total result is shown as Actual Angle. If the test run is not terminated by a monitoring criterion and the batch result is greater than or equal to 360 degrees, it is evaluated and displayed as OK. Monitoring criteria are the torque and a monitoring time.

If the torque exceeds 15 % of the calibration value (even during the dwell time), or if the monitoring time of 4 seconds expires, the test run is terminated with a TQ> or TMAX result. However, you specifically need to check whether the output shaft has actually turned by the value indicated (e. g. by placing a mark on the spindle). If the angle reached by the output shaft does not agree with the value displayed, either the angle factor has been entered incorrectly or the resolver is defective.



Speed

T 0.02

RPM466

Voltages

Second line: Current battery voltage. To ensure high utilization potential, this voltage is monitored continuously during fastening operation. If the voltage drops below limit, a warning output on the tool. Third line: Programmed value. This can be changed using the control.

Speed

The start button starts the tool at the maximum speed.

Second line: Current output shaft speed. Third line: Current torque.

Rotational speed measurement is based on the angle information of the resolver. If you release the start button, the tool stops. As a safety function the torque is monitored by the tool transducer. If it exceeds 15 % of its calibrated value, the speed measurement is terminated.



9.3.6 Set position submenu - only with Linking enabled

>Posit
Change
Positi

Selects the position to be used next.

Select Positi 2/6

You can skip the position.

You can select the position to be used next using the function keys:

- <F1>: Activate the previous position.
- <F2>: Activate the next position.
- Press the start button or <F2> longer than 2 seconds to accept the select and

display the next menu item.

Press <F1> longer than 2 seconds to delete the selection and exit the menu.

>Posit Reset Positi

Reset linking to position 1. The machine operator can cancel Linking.

Certif OK 01. 01.04

Displays EAP-TLS certificate. The certificate is used for WLAN encryption.

The display is only shown if a LiveWire tool is used with the L1 measuring card and EAP-TLS encryption is activated.

ſ	Countr
I	code
I	World
L	

•

Various WLAN frequency ranges are available:

- World: worldwide approved
- US/CA: approved in the USA
- EU: approved in Europe
- JP: approved in Japan
- CN: approved in China

Daimler Wirele Active

Display whether Daimler function is active.

9.3.8 WLAN wireless transmission submenu

The WLAN wireless transmission submenu shows the settings being used.

If no actions are carried out, the menu is automatically exited after 60 seconds.

Programming the RF settings for WLAN data transmission is described in the programming manual of the control.



Displays the installed software version of the wireless module.



MAC address display



Display LMC serial number.

IP 010 122.0 77.110

IP address display



Subnet display

9.3.7 LMC submenu

MAC 00302e e162f8

MAC address display.



Gat010 122.0 61.001	Gateway display	Active Display of channel currently used channel
Host 122.0 61.001	Display of tool designation in a network.	ScanCh 1,5,9,7,2
SSID APEX	SSID display Only a maximum of the first 12 charac- ters are displayed.	Baud rate display
BSSID	BSSID display Access point with which the WLAN socket tray is connected.	Comm. TCP Selection of communication tool – con- trol: TCP / UDP
WLAN Signal	Change to graphic view of current qual- ity of wireless signal via function key <f1>.</f1>	9.4 System error messages
WLAN	When the start button is pressed, the current strength of the wireless signal is displayed as an RSSI value. The higher the RSSI value, the better the signal strength:	event of serious hardware errors, the tool is not enabled again even after the error is acknowledged, and must be returned to the manufacturer for repair.
	 5 bars: > -48 dBm 4 bars: -55 dBm 3 bars: -60 dBm 2 bars: -66 dBm 1 bar: -72 dBm 	Servo Error InitInitialization error in tool servo.1.Remove the battery and then re- insert it. If this does not help:2.Return tool to Sales & Service Cen- ters for repair.
S: 60	S = Signal strength (dBm) For a reliable signal strength, the signal strength should be > -73 dBm.	Servo Error PWMSpeed specification from the measuring board to the servo is faulty.1.Remove the battery and then re- insert it. If this does not help:2.Return tool to Sales & Service Cen- term for service)
Roamin	Sensitivity display Tool reaction to Access Point change	ters for repair. Servo Fror Too much power is being demanded from the tool.
TxLeis	Transmission output display	 Switch the tool off for a time so that it can cool down. Increase the cycle time, reduce the fastening time or the torque.
Wave- bands	Wavebands display	ServoThe servo's current sensor is detecting a current offset error.IOFFReturn tool to Sales & Service Cen- ters for repair.



Servo Error Other	 Collective servo error caused by hard-ware. ▶ Return tool to Sales & Service Centers for repair. 	Tool Error Ident
Servo Error IP	 The current setpoint has been exceeded. There may be a short circuit. Return tool to Sales & Service Cen- 	Tool Error Start
	<i>ters</i> for repair.	
Servo Error Temp >	 The servo has overheated. Switch the tool off for a time so that it can cool down. Increase the cycle time, reduce the 	Transd Ref.V. Error
	fastening time or the torque.	
Servo Error TempM>	 The tool motor has overheated. Switch the tool off for a time so that the motor can cool down. 	Trans CAL Error
	 Increase the cycle time, reduce the fastening time or the torque. 	
Servo Error Voltag	Operating voltage is outside the admissible range.1. Change the battery. If this does not help:	Trans Off Error
	 Return tool to Sales & Service Cen- ters for repair. 	
Servo Error	Current at servo output stage is too high.	
Curr>	 There may be a short circuit. Return tool to Sales & Service Centers for repair. 	Unknow Error
Servo	Tool angle encoder is sending incorrect	
Error Angle	 signals to the servo amplifier. Return tool to Sales & Service Centers for repair. 	Batter empty -> off
	Warns that battery is running low.	
Low voltag warnin	 Recharge battery or replace it with one that is already charged. 	No result
	Servo firmware is not compatible with	
ServoƳ Error Othe80	 With a software is not compatible with measuring board software. Update servo firmware. 	Servic interv warnng
Tool Error Counte	 The rundown counter could not be read or written to. Return tool to Sales & Service Centers for repair. 	



val.

on.

Transducer reference voltage error Return tool to Sales & Service Cen-ters for repair.

Tool memory could not be read.

Two-stage start button defective.

ters for repair.

ters for repair.

Return tool to Sales & Service Cen-

Return tool to Sales & Service Cen-

Transducer calibration voltage error Tool was not discharged at time of calibration.

- 1. Allow tool to discharge and try again. If this does not help:
- 2. Return tool to Sales & Service Cen-

Transducer offset voltage error Tool was not discharged at time of cali-

- Allow tool to discharge and try again. If this does not help:
- 2. Return tool to Sales & Service Cen-

The min. torque for evaluation was not

The service counter has reached the

warning threshold for the service inter-

Acknowledge message once.

The message only appears again once the system is switched back

Repeat the current rundown.

26



Servic Interv	 The service counter has reached the maximum number of rundowns. Tool has locked. Return tool to manufacturer for repair.
LMC Error	 Initialization error <i>LiveWire Memory</i> <i>Chip</i>. Switch the tool on and off again. Check the parameters in the software controller. Insert the WLAN chip again. Replace if necessary. Return tool to manufacturer for repair.
WLAN error	WLAN module programming initialization fault.1. Switch the tool on and off again.2. Check the parameters in the software controller.3. Return tool to manufacturer for repair.
Tool Locked Offline	 The authorized WLAN offline time for the connection was exceeded. Tool is locked until the connection is restored or the tool moves within the wireless transmission range. Move the tool within range of the WLAN access point.
Certif ErrPwd	 The EAP-TLS certificate is encrypted with a password. The entered password does not match the certificate file. Enter correct certificate password.
Certif SrvNot YetVal	 The EAP-TLS certificate on the server is not valid yet. Adjust the validity of the certificate or check the time and date.
Certif SrvExp	The EAP-TLS certificate on the server is expired. ▶ Renew the EAP-TLS certificate on

Renew the EAP-TLS certificate on the server or check the time and date.

Additional messages from »PLUS«

Depending on the software used, different messages relating to the process with the PLUS system can be programmed to appear on the display in addition to the standard tool displays.

1st line Text/ Color	2nd line Text/ Color	3rd line Text/ Color	Description
NEW	PARA	METE RS	New parameters have just been adopted. This does not mean that these parameters will have an immediate effect on the nutrunner/ fastening process. The message is deleted when a new job is initi- ated.
PLUS	None	TMU	Could not determine TMU. The message is deleted when a new job is initi- ated
PLUS	TmuErr	POFL Time Send	PLUS offline, timeout, send error The message is deleted when a new job is initi- ated
No	RS	found	No work step found!
Job	Pos.	>	The job has more than 32 steps.
Job 1	without	action	The job does not involve processing.
No	Job	found	No job found.
Job	TIME	OUT	The job timeout has expired.
Bit 1:	Wait	Remov	Message with exclu- sion character
PLUS	Send	results	PLUS result is sent. The message is deleted when a new job is initi- ated
PLUS	ErgErr	Send	Error sending the PLUS result.



10 Servicing

10.1 Cleaning instructions

For tools with a barcode scanner, the window must be free of dirt. The barcode is not read if the window is dirty.

- Clean it regularly—or immediately, if it becomes dirty using a damp cloth and a conventional window cleaner. Do not use acetone for cleaning.
- Remove contamination on the plastic housing (47BA(...)L) with a commercially available cleaning agent. Do not use acidic cleaners or acetone. These could dissolve the plastic.
- Disinfection of surfaces with alcohol-based disinfectant is permitted.

10.2 Service schedule

A repair is only permitted by Apex Tool Group authorized personnel. Regular service reduces operating faults, repair costs, and downtime. In addition to the following service schedule, implement a safety-related service program that takes the local regulations for repair and service for all operating phases of the tool into account.



Caution

Risk of injury through unintentional activation.

Prior to servicing 47BA disconnect power supply.

After … fastening cycles ^{ab})	Measures		
100,000	 Check to ensure the battery adapter, scanner and wireless adapter are seated securely. Check the tool and power supply for damage. Check to ensure scanner window is transparent. Check to ensure the power supply is clean. Check to ensure battery charger is clean. Check the gearing and angle head for leaks. 		
500,000	 Check power supply guide, lock- ing mechanism and contacts for wear and replace if necessary. Clean the gearing parts with a grease-dissolving agent and re- lubricate. Check the gearing parts for wear, renew as necessary. 		
1 million	 Recommendation: Recalibration of tool, see Recalibration, page 42. 		

After … fastening cycles ^{ab})	Measures	
2.5 million	 General refurbishment of tool. Send it to Sales & Service Center. 	

- a.) For the number of fastening cycles, refer to the counter display in 9.3.4 Administration submenu, page 22
- b.) Use of 80% of maximum torque

10.3 Lubricants

For proper operation and a long service life, use the correct type of grease.

Grease lubricants according to DIN51502/ ISO3498

Order No.	Packing unit [kg]	DIN 51502	LUBRICATION
933027	1	KP1K	Microlube ^a GL 261

a.) Erstschmierung Apex Tool Group



11 Troubleshooting

11.1 General tool

Problem	Possible cause	Measure for mPro400GC (SW S816813)	Measure for mPro400S… (example SW 816841) ^a
Tool doesn't start with counterclock- wise rotation acti- vated.	With counterclock- wise rotation, parameter for speed is set to 0 1/min.	Parameterize Settings for speed le On the control screen Navigator > Standard > Tool Groups.	off rotation. On the control screen Main Menu > Application Builder > Tool Groups
Tool light disabled.	Disabled by param- eter setting.	Parameterize the tool light On the control screen Navigator > Advanced > Tool Group > Extended Tool Settings.	 Press < > on the control. Select the required tool under <i>TM</i> Unit # > Tool Assignment. Press < > >. Make selection under Nutrunner Lighting Function.
Control menu on tool not enabled or only partially enabled.	Disabled by param- eter setting.	On the control screen Navigator > Advanced > Tool Group > Extended Tool Settings, mark the check box Enable Tool Menu or use the drop down list F1 Button on Tool to assign the left function key <f1>.</f1>	 Press < > on the control. Select the required tool under <i>TM</i> Unit # > Tool Assignment. Press < > >. Select function under Control But- ton Settings. Default = Control menu disabled.
Idle speed not reached.	Battery voltage is too low.	Use fully charged battery.	·
Expected number of test rundowns is not	Battery is not fully charged.	Use fully charged battery.	
achieved with one charge of the bat- tery.	The warning thresh- old for undervolt- age is not set to minimum value.	Navigator > Tool Setup > Tool set- tings > Others, reduce the Under- voltage (V).	 > under Tool Assignment 3. Press < >> 4. Under Energy Management reduce the Undervoltage Thresh- old.
	High torque is needed during a fastening sequence, e.g. for coated fas- teners.		beriod of time, e.g. for several turns, the ved with one battery charge will be sig-
	Battery has too many charging cycles.	After 800 charging cycles the capacity is reduced to approx. 60%.	

a.) Software-dependent measure. Discrepancy possible when using Custom Tool Software.

11.2 Infrared data communication between controller and tool

Problem	Possible cause	Measure for mPro400GC (SW S816813)	Measure for mPro400S… (example SW 816841) ^a
No infrared data communication between the control- ler and tool.	Incorrect interface selected for the con- nection to the con- troller.	On the control screen Navigator > Utilities > System Settings > Radio Frequency (RF) Configuration LiveWire/CellCore, check the correct IRDA Connec- tion.	 On the control screen Main Menu System Programming > Service TMA Configuration > Communication with Tool, check the correct IRDA Connection.
		Check whether the tool holder is c	onnected at the selected interface.
	Selected interface is used for serial data	Do not use the same interface for serial data transmission and infrared data transmission.	
	transmission.	Navigator > Utilities > System Settings > Radio Frequency (RF) Configuration	Check on the control screen Main menu > System Programming > Ser- vice > TMA Configuration > Communi- cation with Tool
		 Is serial data transmission acti- vated (selection <i>RF Mode</i> is not <i>None</i>)? 	 Is serial data transmission acti- vated (selection <i>RF Mode</i> is not <i>None</i>)?
		 Is the same interface selected? If so, select a different interface or deactivate serial data transmis- sion. 	 Is the same interface selected? If yes, select another interface under <i>Main Menu</i> > System Pro- gramming < System Program- ming > Serial Ports
		All tools must be checked.	 Disable serial data transmission. All tools must be checked.

a.) Software-dependent measure. Discrepancy possible when using Custom Tool Software.

11.3 WLAN data communication between controller and tool

Problem	Possible cause	Measure for mPro400GC (SW S816813)	Measure for mPro400S… (example SW 816841) ^a	
No WLAN data communication between the control- ler and tool.	The IP address of the tool is not cor- rectly entered in the control.	 On the control screen <i>Tool Setup</i>, check whether the IP address of the tool has been entered in the field <i>Type</i>. Otherwise, mark the line and <edit>.</edit> IP address of tool – see Tool in sub- menu <i>Wireless Settings</i>. 	 Press < > on the control. Select the required tool under <i>TI</i> Unit # > Tool Assignment. Press < > >. Enter the IP address under <i>Tool</i> Address. IP address of tool – see Tool in sub- menu Wireless Settings. 	
	Tool not yet param- eterized with the correct WLAN set- tings.	On the control screen Navigator > Utilities > System Settings > Radio Frequency (RF) Configuration LiveWire/CellCore parameterize the tool with the infrared interface with the correct WLAN settings.	 On the control screen Main Menu System Programming > Service TMA Configuration > Communication with Tool, select > RF Mode WLAN. Parameterize the tool with the correct settings via the infrared interface. 	



EN

Problem	Possible cause	Measure for mPro400GCMeasure for mPro400S (examp SW 816813)		
No WLAN data communication between the control- ler and tool.	WLAN settings are different for control and access point.	 On the control screen Tool Navigator > Utilities > System Settings Radio Frequency (RF) Configuration LiveWire/CellCore, check whether the WLAN settings for the tool agree with the settings for the access points (network name, encryption, network key). On the control screen Main Mether System Programming > Servite > System Programming > Servite > TMA Configuration > Communication with Tool, check whether the WLAN settings for the access points (network name, encryption, network key). 		
	A filter for MAC addresses is acti- vated at the Access Point.	 Add the MAC address for the tool to the list of approved addresses at the Access Point. MAC adress of tool – see Label above the battery On the tool in the <i>Wireless Settings</i> submenu. 		
	Port 4001 is dis- abled by a firewall.	 Configure the firewall such that the required IP/MAC addresses can use port 4001. 		
	The wireless chan- nel at the access point is outside the range supported by the tool.	To change the wireless channel setting at the access point to the right wireless channel with respect to country code: EU 1–13; World 1–11 (se Installation Manual P1894E).		
	Tool is already assigned to another control.	Check whether another control already has a connection to this tool. Ir other words, another tool is using the same IP address.		
IP address cannot be pinged.	IP Address already exists in network. In this case, the tool will not build up a connection.	Check the physical connection (RSSI values). Check the assigned IP address.		
Occasional interrup- tions in WLAN data communication.	Distance between the access point and the tool is too great.	 Check the signal strength at the tool in the <i>Wireless Setting</i> submenu. If necessary, reduce the distance between the access point and the tool 		
	The tool is already assigned to another control.	 Check whether the tool (IP address) is also assigned to another control. If yes, delete the assignment in the other control. A tool can only be assigned to one control. 		
	Excessive data traf- fic on WLAN Net- work.	Reduce data traffic on WLAN Network.		
		 On the control screen Basic, increase the Initial Torque. On the control screen Navigator > Advanced > Control- ler > Trace Recording, disable the torque graph data transmission. On the control screen Main Met > Application Builder > Settings Fastening Stages > Fastening Stage # > Fastening Sequence increase the Initial Torque. On the control screen Main Met > System Programming > Spe- cial Functions > MWF, disable the torque graph data transmission 		

a.) Software-dependent measure. Discrepancy possible when using Custom Tool Software.



11.4 Reset tool

This key combination activates the *Service* menu. Here, the tool can be shut off or reset to the delivery settings.

Note The foll

The following will then be deleted:

- the internal memory (programming)
- the current fastening job
- rundown data not yet transmitted to the control

Once selected, there is no way back to the current fastening job.





12 Spare parts

12 EN



Always use only original *Cleco* spare parts. Failure to comply with this instruction can result in decreased performance and an increased need for servicing. Installing spare parts from other manufacturers will void all manufacturer's warranties. Information, but no warning of hazards.

Table 12.1			
Туре	Gearing + Attachment	Gearing	Attachment
47BSYB10D3	942246PT	-	
47BSYB15D3	942240PT	-	
47BSYB30D3	942242PT	-	
47BSYB45D3		302224PT	942238PT
47BSYB60D4		543465-01	942239PT

12.1 Gearing + Attachment 942246PT





Index	Order no.	Quantity	1	Description	Dimension
1	541044	1	2	Pinion Adapter	25,98X0,94 IR
2	541898	1	2	Extension Pinion	
3	800116	1	2	Retaining Ring	28,24X 0,78
4	541887	1		Washer	
5	542724	2	4	O-Ring	
6	542722	1		Ring Gear	
7	541899	1	2	Slip-On Gear (17T)	3,X5,X 7,
8	542233	1		Idler Plate	
9	541894	3	6	Planet Gear (17T)	
10	203749	3	6	Needle Bearing	
11	541888	3	6	Planet Pin	3,X5,X 7,
12	541897	3	6	Planet Gear	
13	203749	3	6	Needle Bearing	15,88X 28,58X 1,56
14	541917	1		Output Spindle - Pin (includes Ref. 15-17)	
15	24499	1	3	Button	
16	9D6481	1	3	Spring	
17	26989PT	1	3	Plug	
22	1019356	1	2	Wave Washer	
23	942249PT	1		Gear Case	
24	935257	1		Front Nut	
25	542134	1		Spline Guard	
26	542089	2	4	Ball Bearing	
27	541775	1		Bearing Spacer	
28	542097	1		Retaining Nut	
29	542076	1	3	Retaining Ring	
30	541919	1		Spindle Washer	
31	800216	1	3	Retaining Ring	
32	542127	1		Reaction Bar	

1.) Recommended spare part for every 5 tools



12.2 Gearing + Attachment 942240PT



12



Index	Order no.	Quantity	1	Description	Dimension
1	541044	1	2	Pinion Adapter	
2	541898	1	2	Extension Pinion	
3	800116	1	2	Retaining Ring	9,58X 20,37X 0,79
4	541887	1		Washer	
5	542724	2	4	O-Ring	
6	542668	1		Ring Gear	
7	542671	1		Idler Plate	
8	541893	3	6	Planet Gear (21T	
9	203749	3	6	Needle Bearing	
10	542666	3	6	Planet Pin	
11	542669	3	6	Planet Gear (17T)	
12	203784PT	3	6	Needle Bearing	
13	542670	1		Output Spindle - Pin (includes Ref. 14-16)	4 x 32
14	24499	1	3	Button	6,4 x 23,8
15	9D6481	1	3	Spring	
16	26989PT	1	3	Plug	
21	1019356	1	2	Wave Washer	
22	942241PT	1		Gear Case	#632 x 25,4
23	935257	1		Front Nut	#632 x 12,7
24	542134	1		Spline Guard	
25	542089	2	4	Ball Bearing	
26	542672	1		Bearing Spacer	
27	542097	1		Retaining Nut	0,05
28	542076	1	3	Retaining Ring	0,25
29	541919	1		Spindle Washer	
30	800216	1	3	Retaining Ring	
31	542127	1		Reaction Bar	

1.) Recommended spare part for every 5 tools
Cleco[®] Production Tools

12.3 Gearing + Attachment 942242PT



C	eco
Р	roduction Tools

	١		2	
ľ		1	N	1

Index	Order no.	Quantity	1	Description	Dimension
1	541044	1	2	Pinion Adapter	
2	541898	1	2	Extension Pinion	
3	800116	1	3	Retaining Ring	9,58X 20,37X 0,79
4	541887	1		Washer	
5	542724	2	6	O-Ring	
6	935748	1		Ring Gear	
7	935754	1		Planetary Gear Carrier	
8	541893	3	6	Planetary Gear (21T)	
9	930228	6	12	Planetary Gear Needle Bearing	
10	935944	3	6	Planetary Gear	
11	935551	3	6	Planetary Gear Pin	
12	942244PT	1		Output Spindle - Pin Retainer (includes Ref. 13-15)	
13	24499	1	3	Button	
14	9D6481	1	3	Spring	
15	26989PT	1	3	Plug	
21	942243PT	1		Gear Case	
22	542134	1		Spline Guard	
23	935257	1		Front Nut	#6-32 x 25,4
24	542089	2	4	Ball Bearing	#6-32 x 15,9
25	542672	1		Bearing Spacer	
26	542097	1		Retaining Nut	
27	542076	1	2	Retaining Ring	0,05
28	541919	1	2	Spindle Washer	0,25
29	800216	1	2	Retaining Ring	
30	542127	1		Reaction Bar	

1.) Recommended spare part for every 5 tools



12.4 Gearing 942238PT, 942239PT



12 EN



Index	Order no.	Quantity	1	Description	Dimension
1	800116	1	2	Retaining Ring	
2	541887	1		Retention Washer	
3	542724	2	6	O-Ring	9,58X 20,37X 0,79
4	542722	1		Ring Gear	
5	541894	3	6	Planet Gear (17T)	
6	203749	6	12	Needle Bearing	
7	541899	1	1	Slip-On Gear	
8	Table 12.2	1		Planet Carrier	
9	541888	3	6	Planet Gear Pin	
10	Table 12.2	3	6	Planet Gear	
11	Table 12.2	1		Lower Gear Cage	
12	502983	1		Thrust Race	
13	500528	1	2	Needle Bearing	
14	542829	1		Attachment Adapter (includes Ref. 13)	
15	543462-02	1		Gear Case Nut	
16	541044	1	2	Pinion Adapter	
17	541898	1	2	Extension Pinion	

1.) Recommended spare part for every 5 tools

Table 12.2

Index	Quantity	Description	47BSYB45D3	47BSYB60D4
8	1	Planet Carrier	542230	542233
10	3	Planet Gear	541894 (17T)	541897 (20T)
11	1	Lower Gear Cage	542079	542099



12.5 Attachment





Index	Order no.	Quantity	1	Description	Dimension
	Table 12.3	1		Abtrieb / Attachment	25,98X0,94 IR
1	543461	1		Gear Case	
2	203253	1	2	Needle Bearing	28,24X 0,78
3	502981	1		Thrust Race	
4	92100120	1	2	Ball Bearing	
5	Table 12.3	1		Output Spindle - Pin (includes Ref. 6-7-8)	3,X5,X 7,
6	24499	1	3	Retainer Button	
7	26989	1	3	Plug Retainer	
8	9D6481	1	3	Spring	
9	543506	3	6	Planet Pin	3,X5,X 7,
10	541488	6	12	Needle Bearing	
11	543457	3	6	Planet Gear (17T)	15,88X 28,58X 1,56
12	543463	1		Gear Case Adapter	
13	93140030	1	2	Oil Seal	
14	48047128	1		Torque Bar (Steel)	
15	11841013	1		Lock Nut	
16	543456	1	1	Pinion Shaft	

1.) Recommended spare part for every 5 tools

Table 12.3

Index	Quantity	Description	47BSYB45D3	47BSYB60D4				
		Attachment	302224PT	543465-01				
5	1	Output Spindle - Pin (includes Ref. 6-7-8)	302223PT	543455-01				





Table 12.4

Order no.	IrDA	For tool ()	47	52	53	54
935290	×	47BT()	935292	935303	935170	917735
935395	-			-	-	-
935999	×	47BC()	935942	935303	935170	917735
935998	_			_	_	_

Index	Order no.	Quantity	Description	Dimension
45	S900983	2	сар	40 X 40
46	S900418	2	slot nut	M 8
47	Table 12.4	1	brace	
48	935293	1	support	
49	935294	1	support	
50	935291	2	plug	
51	902490	2	cap screw	M8 X 65
52	Table 12.4	1	locking cover	
53	Table 12.4	1	IrDA-Serial Adapter	
54	Table 12.4	1	dowel pin	6 X 50



13 Service Notes

1			
Illustration	Reference	Tightening torqu	е
		Ft-Lbs (in-lbs)	Nm
Н	24	35-40	47-54
	28	30-35	41-47
I	23	35-40	47-54
	27	30-35	41-47

Illustration	Reference	Tightening torque		
		Ft-Lbs (in-lbs)	Nm	
J	23	35-40	47-54	
	26	30-35	41-47	
G	15	35-40	47-54	
К	1	35-40	47-54	
	15	35-40	47-54	



Schmiermittel

BestNr.	Verp. Einheit	DIN51502/	KLUBER
	[kg]	ISO3498	LUBRICATION
933027	1	KP1K	Microlube ¹ GL 261

1.) Erstschmierung Apex Tool Group







14.1 Dimensions

Gearing 10 – 30 Nm

Туре	L1	L2
47BSYB10D3	503.5	70.5
47BSYB15D3	509.5	76.5
47BSYB30D3	513.5	80.5



Gearing 45 – 60 Nm

Туре	L1	L2
47BSYB45D4	578.5	145.5
47BSYB60D4	581.5	148.5





14.2 Dimension of tool holder 935290 / 935395 (optional)



14.3 Performance data

Туре	Recomm	nended	Idling	Idling	Screw	Weight	Calibra	tion data
	torque	range	speed Battery pack 26 V	speed PM48/ Battery pack 44 V	size 8.8	with- out PS ^a	Torque (nominal)	Angle pulses (Resolver)
	Nm max.	Nm min.	rpm	rpm	mm	kg	Nm	1 degrees
47BSYB10D3	10	3	750	1375	M6	1,8	11,95	1,0331
47BSYB15D3	15	5	570	1050	M6	1,8	16,73	1,3529
47BSYB30D3	30	10	275	485	M8	1,8	30,20	1,9091
47BSYB45D4	45	15	205	355	M8	2,7	58,15	2,5959
47BSYB60D4	60	21	145	250	M10	2,8	57,00	3,6631

a.) Weight of power supply: battery pack 26 V 935377 0.50 kg, battery pack 44 V 936400PT 0.85 kg



14.4 Electrical Data

14.4.1Output stage servo electronics

Features	Data
Nominal motor phase cur- rent	8 A peak value, sine
Rated output	150 VA
Maximum power	500 VA

14.4.2Control electronics

Features	Data
Rated voltage	26 V
Nominal current in <i>Active</i> operating mode	105 mA
Nominal current in <i>Standby</i> operating mode	95 mA
Nominal current in <i>Power-saving</i> operating mode	55 mA
Nominal current in <i>Sleep</i> operating mode	< 1 mA

14.4.3IrDA interface port

Features	Data
Supply voltage	5.0 V (4.8 to 5.5 V)
Power consumption	0.30 VA
Maximum current	11 mA
Transmission rate	57.6 kbit/s
Parity Bit	No
Data Bit	8 bit
Stop Bit	1 bit
Error check	CRC

14.4.4WLAN data transmission

Features	Data
Standard	IEEE 802.11ac/b/g/n IEEE 802.11d/e/i/h/r/w
Safety	 WPA, WPA2 TKIP, AES/CCMP hard- ware accelerator LEAP, PEAP^a, EAP- TTLS
Range	up to 50 m (typ. @ 2,4 GHz) up to 30 m (typ. @ 5 GHz)
Channels ^b	1 – 13 (2,412 – 2,472 GHz) 36, 40, 44, 48, 52, 56, 60, 64, 100, 104, 108, 112, 116, 120, 124, 128, 132, 136, 140, 149, 153, 157, 161, 165 (5,180 – 5,825 GHz)
Transmission power:	18 dBm EIRP (radiated)

Features	Data
Sensitivity	-95 dBm (typ. @ EIRP 2,4 GHz) -89 dBm (typ. @ EIRP 5 GHz)
Standards	Europe (RED) US (FCC/CFR 47 part 15) Canada (IC RSS) Japan (MIC) Taiwan (NCC) China (SRRC) China (SRRC) South Korea (KCC) Australia (ACMA) New Zealand; Brazil (Anatel) South Africa (ICASA)

a.) PEAP (without client certificate)

b.) If permitted by IEEE 802.11d

14.4.5Torque transducer

Torque is measured by a reaction transducer with expandable measurement strips. The reaction transducer is positioned between the motor and the gears in the handle housing.

Features	Data
Nominal calibration	see 14.4 Electrical Data, page 48
Sensitivity	2 mV/V
Bridge ohms	1000 Ohm
Precision class	0.5% of final value
Linearity error	+0.25% of final value
Measurement range	-125% to +125% of final value

14.5 Ambient conditions

Features	Data
Ambient temperature	32 °F to +104 °F (0 °C to +40 °C)
Humidity	0 to 80 % (at +40 °C), not with dew
Working height	up to 3000 m above sea level
Storage temperature without power supply)	4 °F to 158° F (-20 °C to +70° C)
Degree of protection DIN EN 60529	IP40
Protection class DIN EN 61140 (VDE 0 140-1)	111

15 Service





Senden Sie im Reparaturfall das komplette Werkzeug an *Sales & Service Center*! Eine Reparatur von Getriebe und Winkelkopf ist nur von Apex Tool Group autorisiertem Personal erlaubt. Das Öffnen des Werkzeugs bedeutet den Verlust der Gewährleistung.

Rekalibrierung

Im Anlieferungszustand des *Cleco*-Werkzeuges sind die typspezifischen Kalibrierdaten auf der integrierten Schraubelektronik gespeichert. Ist im Servicefall ein Austausch des Drehmomentaufnehmers, der Schraubelektronik oder eine Rekalibrierung erforderlich, bitte das *Cleco*-Werkzeug an *Sales & Service Center* einsenden. So ist sichergestellt, dass nach den Servicearbeiten die evtl. nötige Aktualisierung der Kalibrierdaten richtig erfolgt.

16 Entsorgung

Bestandteile und Hilfsmittel des Werkzeugs bergen Risiken für Gesundheit und Umwelt. Auf eine fachgerechte Entsorgung achten:

- Hilfsstoffe (Öle, Fette) beim Ablassen auffangen und fachgerecht entsorgen.
- Bestandteile der Verpackung trennen und sortenrein entsorgen.
- Örtlich geltende Vorschriften beachten.



Allgemein gültige Entsorgungsrichtlinien, wie Elektro- und Elektronikgerätegesetz (ElektroG) und Batteriegesetz (BattG) beachten:

Verbrauchte Akkus müssen entsorgt werden. Werkzeug und defekte / verbrauchte Energieversorgungen bei ihrer betrieblichen Sammeleinrichtung oder bei Sales & Service Center abgeben.

POWER TOOLS SALES & SERVICE CENTERS

Please note that all locations may not service all products. Contact the nearest Cleco® Sales & Service Center for the appropriate facility to handle your service requirements.

Sales Center 🔑 Service Center

NORTH AMERICA | SOUTH AMERICA

DETROIT, MICHIGAN 🔶 🌽 Apex Tool Group 2630 Superior Court Auburn Hills, MI 48236 Phone: +1 (248) 393-5644 Fax: +1 (248) 391-6295

LEXINGTON, SOUTH CAROLINA Apex Tool Group 670 Industrial Drive Lexington, SC 29072 Phone: +1 (800) 845-5629 Phone: +1 (919) 387-0099 Fax: +1 (803) 358-7681

MEXICO 🅢 🎤 Apex Tool Group Vialidad El Pueblito #103 Parque Industrial Querétaro Querétaro, QRO 76220 Mexico Phone: +52 (442) 211 3800 Fax: +52 (800) 685 5560

BRAZIL 🌒 🎤 Apex Tool Group Av. Liberdade, 4055 Zona Industrial Iporanga Sorocaba, São Paulo CEP# 18087-170 Brazil Phone: +55 15 3238 3870 Fax: +55 15 3238 3938

EUROPE | MIDDLE EAST | AFRICA

ENGLAND
Apex Tool Group GmbH
C/O Spline Gauges
Piccadilly, Tamworth
Staffordshire B78 2ER
United Kingdom
Phone: +44 1827 8727 71
Fax: +44 1827 8741 28

GERMANY 🌧 🎤 Apex Tool Group GmbH Industriestraße 1 73463 Westhausen Germany Phone: +49 (0) 73 63 81 0 Fax: +49 (0) 73 63 81 222

HUNGARY 🌧 🎤 Apex Tool Group Hungária Kft. Platánfa u. 2 9027 Györ Hungary Phone: +36 96 66 1383 FAX: +36 96 66 1135

ASIA PACIFIC-

AUSTRALIA 🦽 Apex Tool Group 519 Nurigong Street, Albury NSW2640 Australia Phone: +61 2 6058 0300

CHINA 🌒 🎤 Apex Power Tool Trading (Shanghai) Co., Ltd. 2nd Floor, Area C 177 Bi Bo Road Pu Dong New Area, Shanghai Indialand Global China 201203 P.R.C. Phone: +86 21 60880320 Fax: +86 21 60880298

INDIA 🌒 🎤 Apex Power Tool India Private Limited Gala No. 1. Plot No. 5 S. No. 234, 235 & 245 Industrial Park Taluka-Mulsi, Phase I Hinjawadi, Pune 411057 Maharashtra, India Phone: +91 020 66761111 JAPAN 🛷 🎤 Apex Tool Group Japan Korin-Kaikan 5F, 3-6-23 Shibakoen, Minato-Ku, Tokyo 105-0011, JAPAN Phone: +81-3-6450-1840 Fax: +81-3-6450-1841

KOREA

Apex Tool Group Korea #1503, Hibrand Living Bldg., 215 Yangjae-dong, Seocho-gu, Seoul 137-924, Korea Phone: +82-2-2155-0250 Fax: +82-2-2155-0252



Apex Tool Group, LLC

Phone: +1 (800) 845-5629 Phone: +1 (919) 387-0099 Fax: +1 (803) 358-7681 www.ClecoTools.com www.ClecoTools.de